
Important Instructions for Headphone Cable Connection

If the cable is not fully seated or plugged in with the wrong end, you may experience no audio or intermittent audio through one of the channels.

1.2 meter portable cable with mic and controls for Apple or Android device: (For the one without mic and controls, both ends are interchangeable.)



3 meter cable with 3.5 mm plug and screw-on 6.35 mm adapter:

